

# Beltpac / All-in-One Configuration

You can adjust the settings of your Beltpacs / All-in-Ones. When you change the settings, the Beltpac / All-in-One will store this in memory, and you will not need to repeat these steps. You can change these settings at any time, as many times as you wish.

## **STEPS TO CONFIGURE YOUR BELTPAC / ALL-IN-ONE AS PUSH-TO-TALK**

1. Make sure the Beltpac / All-in-One is turned off and a headset is connected to it (Beltpac only).
2. **PRESS** and **HOLD** the **ALL** and **VOLUME DOWN** buttons, then **PRESS PWR**. Once the lights come on, let go.

*If done correctly, the Beltpac / All-in-One will say "Hands free off".*

## **STEPS TO CONFIGURE YOUR BELTPAC / ALL-IN-ONE AS OPEN-MIC**

1. Make sure the Beltpac / All-in-One is turned off and a headset is connected to it (Beltpac only).
2. **PRESS** and **HOLD** the **ALL** and **VOLUME UP** buttons, then **PRESS PWR**. Once the lights come on, let go.

*If done correctly, the Beltpac / All-in-One will say "Hands free on".*

If you have any questions, please feel free to call us at **724-337-1400**.