

Antenna Extender Kit Guide

The HME system requires a clear line of sight between the base station and the field units. Antenna Extender Kits allow you get around objects that would otherwise block your line of sight, the most common being tinted glass in the press box. If possible, opening a window between the base station antennas and the field will open up the line of sight. If that is not possible, use an Antenna Extender Kit to get around the glass.

SETTING UP YOUR ANTENNA EXTENDER KIT

1. Screw the two ends of the Antenna Extender Kit onto the antenna jacks located on the back of the Base Station / Extender Base.
2. Run the Antenna Extender Kit Base (white box) to get around the obstruction (i.e. out a door, window, or other opening).
3. Attach the Antenna Extender Kit Base (white box) to a window, wall, or other solid surface. Make sure the crown of the Antenna Extender Kit Base (white box) is facing the field and that it is angled down towards the field (the longer legs of the base should be on top with the wires entering the base from the bottom).

YOUR ANTENNA EXTENDER KIT IS NOW SETUP!

If you have any questions, please feel free to call us at **724-337-1400**.