

# Registering Beltpac / All-in-One

When you add an additional Beltpac or All-in-One to your system, you **MUST** register it to the appropriate Base Station or EB-300 Open-Mic Expander in order to use it. Please see the chart titled HME RECOMMENDED SYSTEM CONFIGURATIONS to determine which Base Station / Open-Mic expander you need to register it to, and if the Beltpac / All-in-One can be Open-Mic or needs to be Push-to-Talk. Then follow the steps below.

## STEPS TO REGISTER YOUR BELTPAC / ALL-IN-ONE

1. Power on your Base Station(s) and Open-Mic Expander (if you have one).
2. Make sure the Beltpac / All-in-One is turned off and a headset is connected to it (Beltpac only).
3. **PRESS** the **REGISTER** button on the appropriate Base Station / Open-Mic Expander (see HME RECOMMENDED SYSTEM CONFIGURATIONS).
4. **PRESS** and **HOLD** the **ALL** button on the Beltpac / All-in-One and then **PRESS** the **PWR** button. Once the lights come on, let go.

*If done correctly, the Beltpac / All-in-One will blink red and you will hear it say "Begin registration". After a few seconds, the lights will become solid green and you will hear "Registration complete". The registration process can take anywhere from two seconds to almost half a minute. If after 30 seconds you do not hear "Registration complete", try again.*

## **YOUR BELTPAC / ALL-IN-ONE IS NOW REGISTERED!**

If you need to configure the Beltpac / All-in-One as Push-to-Talk, please see BELTPAC / ALL-IN-ONE CONFIGURATION. By default, all Beltpacs / All-in-Ones are Open-Mic.

If you have any questions, please feel free to call us at **724-337-1400**.