Two Base Station and EB-300 Configuration

When you have two Base Stations and an EB-300, you **MUST** register them together and then register Beltpacs / All-in-Ones accordingly. In order to ensure your system is properly configured, we **ALWAYS RECOMMEND** clearing your system completely first. This process takes approximately 10 minutes to complete.

Refer to the Chart on HME RECOMMENDED SYSTEM CONFIGURATIONS to determine the optimal configuration for your system.

Please follow the steps below to configure your multiple Base Station system.

- 1. <u>Power on the Base Stations and EB-300</u> Each Base Station comes with a wall plug and power pack. The EB-300 comes with a power-splitter cable, allowing you to power one Base Station and EB-300 from the same wall plug and power pack. Connect the male end of the power pack into the female end of the power splitter. Then connect one male end of the power splitter into the Base Station, and the other into the EB-300.
- 2. Clear each Base Station and EB-300 ON EACH, do the following in order:
 - (1) PRESS IN and HOLD the RESET Button.
 - (2) PRESS IN and HOLD the CLEAR Button.
 - (3) **LIFT UP** on the **RESET** button.
 - (4) LIFT UP on the CLEAR.

If this is done correctly, a "C" will appear in the LED display.

- 3. <u>Configure Primary and Secondary Stations</u> When you have two Base Stations, one must be set as the Primary station, and the other station as Secondary.
 - (1) To set the Primary station, select a Base Station and set the switch labeled BASE on the right side to PRI.
 - (2) To set the Secondary station, set the switch labeled **BASE** on the right side to **SEC**.

Two Base Station and EB-300 Configuration (Page 2)

- 4. **Register Base Stations Together** With the Base Stations in front of you:
 - (1) **PRESS** the **REGISTER** button on the Primary Base Station (a small "o" will appear in the LED Display).
 - (2) **PRESS** the **REGISTER** button **ONCE** on the Secondary Base Station (a "1" will appear in the Secondary Base's LED display). Wait until you see a single underscore "_" appear in the Secondary Base's. The Base Stations are now registered together.
- 5. Register the EB-300 to the Base Station With the Primary Base Station and EB-300 in front of you:
 - (1) **PRESS** the **REGISTER** button on the Primary Base Station (a small "o" will appear in the LED Display).
 - (2) **PRESS** the **REGISTER** button **TWICE** on the EB-300 (a "2" will appear in the EB-300's LED display).

Wait until you see a single underscore "_" appear in the EB-300 display. The Base Station and EB-300 are now registered together.

- 6. Register Beltpac / All-in-One to the Primary Base Station FOR EACH Beltpac / All-in-One, do the following in order:
 - (1) Make sure the beltpac is turned OFF and a headset is connected to it (beltpac only).
 - (2) PRESS the REGISTER Button on the Primary Base Station (the small "o" should appear).
 - (3) **PRESS** and **HOLD** the **ALL** button on the Beltpac / All-in-One, then **PRESS** the **PWR** button. Once the lights turn on the Beltpac / All-in-One, let go.

If done correctly, the Beltpac / All-in-One will blink red and say "Begin registration". After a few seconds (anywhere from 2 seconds to 15 seconds), its lights will turn green and will say "Registration complete". It is now registered.

Repeat process for each Beltpac / All-in-One.

Two Base Station and EB-300 Configuration (Page 3)

- 7. Register Beltpacs / All-in-Ones to Secondary Base Station FOR EACH Beltpac / All-in-One, do the following in order:
 - (1) Make sure the Beltpac / All-in-One is turned OFF and a headset is connected to it (beltpac only).
 - (2) **PRESS** the **REGISTER** Button on the Secondary Base Station (the small "o" should appear).
 - (3) **PRESS** and **HOLD** the **ALL** button on the Beltpac / All-in-One, then **PRESS** the **PWR** button. Once the lights turn on the Beltpac / All-in-One, let go.

If done correctly, the Beltpac / All-in-One will blink red and say "Begin registration". After a few seconds (anywhere from 2 seconds to 15 seconds), its lights will turn green and will say "Registration complete". It is now registered.

Repeat process for each Beltpac / All-in-One.

- 8. Register Remaining Beltpacs / All-in-Ones to EB-300 FOR EACH Beltpac / All-in-One, do the following in order:
 - (1) Make sure the Beltpac / All-in-One is turned OFF and a headset is connected to it (beltpac only).
 - (2) **PRESS** the **REGISTER** Button on the EB-300 (the small "o" should appear).
 - (3) **PRESS** and **HOLD** the **ALL** button on the Beltpac / All-in-One, then **PRESS** the **PWR** button. Once the lights turn on the Beltpac / All-in-One, let go.

If done correctly, the Beltpac / All-in-One will blink red and say "Begin registration". After a few seconds (anywhere from 2 seconds to 15 seconds), its lights will turn green and will say "Registration complete". It is now registered.

Repeat process for each Beltpac / All-in-One.

Two Base Station and EB-300 Configuration (Page 4)

9. <u>Configure Beltpacs / All-in-Ones</u> – Refer to chart HME RECOMMENDED SYSTEM CONFIGURATIONS to determine if any of your Beltpacs / All-in-Ones need to be converted from Open-Mic to Push-to-Talk, or can be converted from Push-to-Talk to Open-Mic. If so, follow the steps below.

STEPS TO CONFIGURE YOUR BELTPAC / ALL-IN-ONE AS PUSH-TO-TALK

- (1) Make sure the Beltpac / All-in-One is turned off and a headset is connected to it (Beltpac only).
- (2) **PRESS** and **HOLD** the **ALL** and **VOLUME DOWN** buttons, then **PRESS PWR**. Once the lights come on, let go.

 If done correctly, the Beltpac / All-in-One will say "Hands free off".

STEPS TO CONFIGURE YOUR BELTPAC / ALL-IN-ONE AS OPEN-MIC

- (1) Make sure the Beltpac / All-in-One is turned off and a headset is connected to it (Beltpac only).
- (2) PRESS and HOLD the ALL and VOLUME UP buttons, then PRESS PWR. Once the lights come on, let go.

If done correctly, the Beltpac / All-in-One will say "Hands free on".

Your system is now completely configured. It is **HIGHLY RECOMMENDED** that you **FULLY TEST** your system between now and your next game to make sure everything was properly configured and works correctly.

If you have any questions, please feel free to call us at **724-337-1400**.